



Radiator grille, remove and install



Remove

1. Detach radiator grille

- Remove 4x body-bound rivet (1)
- Unlock 6x retainer (2)



L0011209

2. When replacing the radiator grille, transfer the attaching parts



Install

3. Install radiator grille

- Lock 6x retainers
- Install 4x body-bound rivet