

Replace full and dipped beam headlamps

N102200




Remove

1. Remove front panelling

2. Remove headlamp

- Unscrew 3x screws (1) and (2)
- Release wiring harness plug (3) and separate
- Remove headlamps



L0011441

3. Remove lights

- Open 2x cover
- Remove 3x bulb
- Remove indicator light
 - Remove bulb from holder




Install

4. Install lights

- Install 3x bulb
- Install indicator light
 - Fit bulb in holder
- Close 2x cover

5. Install headlamp.

- Connect wiring harness plug
- Tighten 3x bolt

6. Attach front panelling 
7. Adjust headlamp 